


© Command post



Complies with EN71



**These instructions are for your safety. Please read through them thoroughly before use .
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE**

Let's get started...

Important information...



Safety	03
Base and positioning	04
Warranty	04
Care maintenance & Recycling	05



In more detail...

Hardware Chart & Fascia bag	06-07
Stacked Parts List	08
Detailed Technical Drawings	10-13
Before you start	14
Assembly instructions	15-32

EN	For a copy of the instructions or a copy in another language please send an email or write to the address below.
F	Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous.
PL	Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej.
RUS	Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу.
TR	Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız.

Check that you have noted all the following instructions



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process
- We advise the use of protective headwear and safety goggles throughout the assembly process
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions
- We advise the use of a scaffold tower when fitting the roof , for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area
- Follow any safety precautions quoted by the manufacturer for any equipment you use
- Check all parts before assembly
- Only use child and animal safe wood preservative
- Do not use creosote
- Allow the wood preservative to fully dry before use
- Regularly check the building for wear and tear
- Children must be supervised at all times while playing with this playhouse
- Not suitable for children under 3 years old.



Important!



EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace
- (4) (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (6) (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

Actual floor area of the building: 1790mm x 1190mm

Total height clearance: 1680mm **See drawing on front cover**

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid.

You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following -

- The building must be raised so it is not in contact with any water retaining base surface (for example grass).
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually
- If your building has been pressure treated or has any pressure treated parts additional treatment need not be applied (except for aesthetic purposes)
- Wood is a natural product and therefore the following are excluded from the warranty
 - Colour changes
 - Warping
 - Splitting

The following are also excluded

- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear

The 5 golden rules of care

- (1) Ensure your base is level and firm
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (see note on pressure treated buildings in warranty section). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore we recommend you seal between all the panels with a silicone based sealant .
- (5) Regularly check your roofing felt for weather damage and leaks

The 7 golden rules of maintenance

- (1) Re apply the timber treatment annually. (see note on pressure treated buildings in warranty section)
- (2) Visually check for weather damage
- (3) Check and replace if necessary any Silicone sealant if used on your building.
- (4) Check the roofing material for wear
- (5) The doors and windows may require periodical adjustment
- (6) Ensure your building is well ventilated especially during hot weather
- (7) During extremely hot periods humidify your building to prevent the timber from drying out .

Recycling and disposal



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations



Building

1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. Roofing felt not currently recycled


Fascia & nail bag contents

Hardware Chart Scale 1:1


8mm Felt Nail
(A0266) x 98



40mm Round head nail
(A0025) x 66




12mm Flat head
Posi-drive screw
(A0027) x 12




Note
These 12mm screws
With roller catch


Black 12mm
Posi-drive screw
(A0029) x 08




25mm Posi-drive screw
(A0032) x 90




Black 25mm
Posi-drive screw
(A0031) x 04




50mm Posi-drive screw
(A0557) x 14



60mm Posi-drive screw
(A0035) x 18



80mm Posi-drive screw
(A0036) x 04




Fascia & nail bag contents

Safety vent
(A0476) x02




Roller catch
(A0090) x03




Black D handle
(A0089) x03




32mm continuous
Hinge 535mm
(A0101) x01




32mm continuous
Hinge 810mm(
A0102) x01




75mm continuous
hinge 785mm
(A0088) x01




Fascia
(A0576) x04




SM view port shutter
(A0093)x01




Sm view port surround
(A0094)x02




View port spacer
(A0095)x02




LG view port shutter
(A0096)x01




Lg view port surround
(A0097)x02




Door block
(A0091) x01




Window frame
(A0098)x06




Window frame
(A0099)x06




Roof bearers
(A0568)x02




Corner strip
(A0569) x02



Cover strip
(A0570) x02




Corner strip
(A0571) x02




Description
(part No) qty

Stacked parts list


Floor
(A0085)x01




End panel
(A0556) x01




Lg angle panel
(A0565) x01




Sm end panel
(A0566)x01



Sm angle panel
(A0564) x01




Door panel
(A0086) x01




Door
(A0087)x01



Lg front panel
(A0562)x01




Roof panels
(A0567) x03



Plastic Glazing
(A0100) x03





1.4 Felt strips
(A0577)x03



Detailed Technical drawing Door & Lg front panels

GB
IE

In more detail.....




Building Photographs


It will be greatly
appreciated if you could
forward images of your
completed
building to -
sales@shiregb.co.uk.

Detailed Technical drawing End Panel

GB
IE



In more detail.....





In more detail.....

Things to check before you start

- ✓ Ensure your base is ready– See page 3
- ✓ Check all parts as listed in the parts lists
- ✓ Read the instructions fully before starting work
- ✓ Follow all the health and safety guidelines



When you see the drill icon
Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need



- Hammer



- Gloves




- Spirit level




- Saw



- Ladder



- Pencil



- 1mm, 3mm 5mm
& 8mm drill bit



- Goggles



- Drill



- A helper for some tasks



- Tape measure & Ruler



- Screwdriver



- Sand paper



- Safety knife

Assembly

These instructions are for your safety. Please read through them thoroughly before use .
Treat all the parts before assembly –see page 5

GB-IE Attach the hinge on the outside long edge of the door using 6 screws into the door and 6 into the door panel

01



Door panel
(A0086) x01




Door
(A0087)x01




75mm x 785mm
Continuous hinge
(A0088)x01






Black D handle
(A0089)x01



25mmScrew
(A0032)x12



25mm Black Screw
(A0031)x04




GB-IE Lay the Door panel "A0086" on the floor, lay the door evenly in position use another panel as support.
Position the door handle about 20mm from the edge of the door





02



3mm




Step 08

Door block
(A0091) x01Roller catch
(A0090)X0112mmScrew
(A0027) x0460mmScrew
(A0056) x02


There are two view port assemblies one is bigger than the other. The biggest one goes on panel "A0562"
It is best to lay all the parts out (on the panels if you wish) before you start. **SEE PAGES 10-12.**

03




Match the continuous hinges to the view port shutters.
Fix the shorter hinge with 10 screws and the longer one with 14 screws.


04




LG view port shutter
(A0096)x01




SM view port shutter
(A0093)x01





32mm x 535mm
Continuous hinge
(A0101)x01



32mm x 810mm
Continuous hinge
(A0102)x01





25mmScrew
(A0032)x24




Align the view port surround level with the edge of the aperture.
 Attach the long pieces with 3 screws each and 1 screw for the short piece


05




Sm view port surround (A0094)x02



view port spacer (A0095)x02




view port surround (A0097)x02





End panel (A0556) x01



Lg front panel (A0562)x01




50mmScrew (A0557)x14




The view port shutters fit inside the surrounds fitted in **step 05** and **open outwards and downwards**. Align the view port shutter level with the edge of the aperture so the loose edge of the hinge is against the edge of the surround below then fix with 14 screws for the long hinge and 10 for the short one. Attach a "D" handle with 4 12mm black screws in the middle of the shutter. Repeat with the other shutter,


06



LG view port shutter (A0096 step11)x01



SM view port shutter (A0093 step11)x01




Step 12 x01




Step 12 x01






Black D handle (A0089)x02



25mmScrew (A0032)x24




12mm Black Screw (A0029)x08




07



Roller catch (A0090)X02







12mm Screw (A0027) x08



Step 13



Step 13



Drill 3 holes **through the thicker part** (not where the step for the glazing to go is) of each of the "A0098" and 2 holes in each of the "A0099" window frame parts.
 Remove the protective film from both sides of the plastic glazing.
 Align the plastic glazing and the window frame over the apertures and attach with 25mm screws.

08



Plastic Glazing (A0100) x03

44x12mm



416mm


Window frame (A0098)x06

44x12mm




309mm


Window frame (A0099)x06









Step 14



Step 14



25mm Screw (A0032)x30



Do not drill the small angled panels "A0086 & A0564"

Only drill 2 holes through the side of the framework on the back of the panels as shown below.


09



Step 15








Step 15



Lg angle panel
(A0565) x01




Sm end panel
(A0566) x01



Place the panels with the cladding overhanging the floor. Panel "A0565" is positioned into the corner of the floor and push the "A0556" up to it, Attach using the holes just drilled.


10








Step 16
(A0556)x01





Lg angle panel
(A0565) x01



60mm Screws
(A0035)x02




11





Sm angle panel
(A0564) x01




Sm end panel
(A0566)x01



60mm Screws
(A0035)x04




12





sm door panel
(A0086) x01



Lg front panel
(A0562) x01




60mm Screws
(A0035) x04




Align the roof panel "A0567" with the lower edge and the cladding and fix with 3 nails into each wall. Position the roof bearer "A0568" half way under the edge of the roof panel that you have fitted, Drill a hole through the side panels at either end of the roof bearer and fix with 2x 80mm screws.


13




Roof panels
(A0567) x01






Roof bearers
(A0568)x01












40mm Nails
(A0025)x09



80mmScrew
(A0036) x02




14

**Roof panels
(A0567) x02****Roof bearers
(A0568) x01.****40mm Nails
(A0025) x27****80mm Screw
(A0036) x02**


If fit corner strips only not the coverstrios over the joins,
 Hold in position level with the bottom of the cladding and mark and trim the top to suit. If necessary .
 Attach the cover strips to each corner with 3x 40mm nails each,

15




44mm 1600mm

Corner strip
 (A0569) x02




44mm 922mm

Corner strip
 (A0571) x02





40mm Nails
 (A0025)x12




Start at the bottom overhanging the felt approximately 40mm down the 3 walls. Nail into the end wall at 100mm centres. Then gently tighten the felt and fix with 2 nails at the top. Overlap the next piece of felt by about 400mm and nail just above the overlap as before. Again tighten and fix at the top with 2 nails. At the top again overhanging the felt approximately 40mm down the 3 walls. And nail as before,





16



1.4m Felt strips
(A0577)x03




9mm Felt nails
(A0266) x98




I Nail the fascia boards into position and carefully trim the excess felt .
Position the cover strips "A0570" over the panel join and mark and trim to fit under the fascia boards.
Attach with 3x 40mm nails each.


17





Fascia
(A0576) x02




Cover strip
(A0570) x02




40mm Nail2
(A0025)x18



18




60mmScrew
(A0035) x06



19



Safety vent
(A0476) x02



customerservice@shiregb.co.uk

Brigstock Road
Wisbech
Cambridgeshire
PE13 3JJ
Tel 01945 465 295

